

2011 Toyota Prius

Fluids

FLUID CAPACITIES

Air Cond Refrigerant

Application	Volume
All Applicable Models	1.04LBS. (0.5KG)
R-134a	

Automatic Transmission Fluid

Application	Volume
Drain and Refill	3.60QTS. (3.4L)
TOYOTA Genuine Automatic Transmission Fluid Type WS	
The fluid capacity is the quantity of reference. Using Fluid other than TOYOTA Genuine Automatic Transmission WS will damage the Transmission.	

Brake Fluid

Application	Volume
All Applicable Models	Top-Off As Required
DOT 3 Brake Fluid	

Engine Coolant

Application	Volume
Power Control Unit	2.20QTS. (2.1L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	
Gasoline engines,w/o Exhaust Heat Recovery System	6.90QTS. (6.5L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	
Gasoline engines,w/Exhaust Heat Recovery System	7.60QTS. (7.2L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	

Engine Oil

Application	Volume
Drain and Refill,w/o Filter	4.10QTS. (3.9L)
SAE 0W-20 Synthetic Oil	
Drain and Refill,w/Filter	4.40QTS. (4.2L)
SAE 0W-20 Synthetic Oil	

Fuel Tank

Application	Volume
All Applicable Models	11.90GALS. (45.0L)

Windshield Washer Fluid

Application	Volume
All Applicable Models	Top-Off As Required
Washer Fluid	
In cold areas where temperatures range below the freezing point, use washer fluid containing antifreeze.	