

**FLUID CAPACITIES****Air Cond Refrigerant**

Application	Volume
<b>All Applicable Models</b>	<b>1.04LBS. ( 0.5KG )</b>
<b>R-134a</b>	

**Automatic Transmission Fluid**

Application	Volume
<b>Drain and Refill</b>	<b>3.00QTS. ( 2.8L )</b>
<b>HONDA CVT Fluid</b>	
Do not mix Honda CVTF with other transmission fluids. Using a transmission fluid other than Honda CVTF may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission. Any damage caused by using a transmission fluid that is not equivalent to Honda CVTF is not covered by Honda's new vehicle warranty.	
<b>Total Capacity</b>	<b>5.50QTS. ( 5.2L )</b>
<b>HONDA CVT Fluid</b>	
Do not mix Honda CVTF with other transmission fluids. Using a transmission fluid other than Honda CVTF may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission. Any damage caused by using a transmission fluid that is not equivalent to Honda CVTF is not covered by Honda's new vehicle warranty.	

**Brake Fluid**

Application	Volume
<b>All Applicable Models</b>	<b>Top-Off As Required</b>
<b>HONDA Heavy Duty Brake Fluid DOT 3</b>	
If DOT 3 Brake Fluid is not available, then DOT 4 or DOT4+ is acceptable. Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.	

**Engine Coolant**

Application	Volume
<b>Drain and Refill</b>	<b>4.81QTS. ( 4.6L )</b>
<b>HONDA Long-life Antifreeze/Coolant Type 2</b>	
This coolant is pre-mixed with 50/50 antifreeze and water. Never add straight antifreeze or plain water. Including the coolant in the reserve tank and that remaining in the engine. If you regularly drive your vehicle under severe conditions in very low temperature (under 31°F, 35°C), a higher concentration of coolant should be used.	
<b>Total Capacity</b>	<b>5.33QTS. ( 5.0L )</b>
<b>HONDA Long-life Antifreeze/Coolant Type 2</b>	
This coolant is pre-mixed with 50/50 antifreeze and water. Never add straight antifreeze or plain water. If you regularly drive your vehicle under severe conditions in very low temperature (under 31°F, 35°C), a higher concentration of coolant should be used.	

**Engine Oil**

Application	Volume
<b>Drain and Refill, w/o Filter</b>	<b>3.20QTS. ( 3.0L )</b>
<b>API - SAE 0W-20 Detergent Oil</b>	
Excluding the oil remaining in the engine. You may use a synthetic motor oil if it meets the same requirements given for a conventional motor oil; it displays the API Certification Seal, and it is the proper weight.	
<b>Drain and Refill, w/Filter</b>	<b>3.40QTS. ( 3.2L )</b>
<b>API - SAE 0W-20 Detergent Oil</b>	
Excluding the oil remaining in the engine. You may use a synthetic motor oil if it meets the same requirements given for a conventional motor oil; it displays the API Certification Seal, and it is the proper weight.	
<b>Total Capacity</b>	<b>4.00QTS. ( 3.8L )</b>
<b>API - SAE 0W-20 Detergent Oil</b>	

## 2011 Honda Insight

### Fluids

You may use a synthetic motor oil if it meets the same requirements given for a conventional motor oil; it displays the API Certification Seal, and it is the proper weight.

#### Fuel Tank

Application	Volume
All Applicable Models	10.60GALS. ( 40.1L )

#### Power Steering Fluid

Application	Volume
All Applicable Models	Top-Off As Required
HONDA Power Steering Fluid	
DO NOT use Automatic Transmission Fluid.	

#### Windshield Washer Fluid

Application	Volume
All Applicable Models	2.60QTS. ( 2.5L )
All Weather Windshield Washer Fluid	
Do not use engine antifreeze or a vinegar/water solution in the windshield washer reservoir.	