

2008 Toyota Prius

Fluids

FLUID CAPACITIES

Air Cond Refrigerant

Application	Volume
All Applicable Models	1.00LBS. (0.5KG)
R-134a	

Automatic Transmission Fluid

Application	Volume
Drain and Refill	3.80QTS. (3.6L)
TOYOTA Genuine Automatic Transmission Fluid Type WS	
ATF JWS3324 or NWS9638.	

Brake Fluid

Application	Volume
All Applicable Models	Top-Off As Required
DOT 3 Brake Fluid	

Engine Coolant

Application	Volume
Power Control Unit	2.90QTS. (2.7L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	
Gasoline engines	9.00QTS. (8.5L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	

Engine Oil

Application	Volume
Drain and Refill,w/o Filter	3.60QTS. (3.4L)
SAE 5W-30 API grade SL "Energy-Conserving" or ILSAC GF-4	
Drain and Refill,w/Filter	3.90QTS. (3.7L)
SAE 5W-30 API grade SL "Energy-Conserving" or ILSAC GF-4	

Fuel Tank

Application	Volume
All Applicable Models	11.90GALS. (45.0L)

Windshield Washer Fluid

Application	Volume
All Applicable Models	Top-Off As Required
Plain water	
In cold areas where temperatures range below the freezing point, use washer fluid containing antifreeze.	