

FLUID CAPACITIES**Air Cond Refrigerant**

Application	Volume
All Applicable Models	1.40LBS. (0.6KG)
R-134a	

Automatic Transmission Fluid

Application	Volume
AWD - Drain and Refill,Rear	1.90QTS. (1.8L)
TOYOTA Genuine Automatic Transmission Fluid Type WS (ATF JWS3324 or NWS9638)	
Drain and Refill,Front,w/o Tow Pkg	4.10QTS. (3.9L)
TOYOTA Genuine Automatic Transmission Fluid Type WS (ATF JWS3324 or NWS9638)	
Drain and Refill,Front,w/Tow Pkg	4.40QTS. (4.2L)
TOYOTA Genuine Automatic Transmission Fluid Type WS (ATF JWS3324 or NWS9638)	

Brake Fluid

Application	Volume
All Applicable Models	Top-Off As Required
DOT 3 Brake Fluid	

Engine Coolant

Application	Volume
Inverter Coolant	3.60QTS. (3.4L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	
All Applicable Models	10.90QTS. (10.3L)
TOYOTA Super Long Life Coolant or equivalent	
DO NOT use plain water alone.	

Engine Oil

Application	Volume
Drain and Refill,w/o Filter	4.80QTS. (4.5L)
API - SAE 5W-30	
TOYOTA Genuine Motor Oil.	
Drain and Refill,w/Filter	5.00QTS. (4.7L)
API - SAE 5W-30	
TOYOTA Genuine Motor Oil.	

Fuel Tank

Application	Volume
All Applicable Models	17.20GALS. (65.1L)

Windshield Washer Fluid

Application	Volume
All Applicable Models	Top-Off As Required
Washer Fluid	
Refer to the freezing temperatures listed on the washer fluid tank.	